



## **ROUND FLANGE SHOWER ROD** **INSTALLATION INSTRUCTIONS**



### **INSTALLATION**

1. Position Wall Flange mounting bracket onto the wall and mark location of where to drill the mounting screw hole.
2. Drill the screw hole.
3. Thread the screw through the mounting flange - placing the toggle on the opposite side. Insert into the hole allowing the toggle to expand into position. Tighten the screw.
4. Measure and trim shower rod to fit the space. Place the shower rod into the Wall Flanges.
5. Place Wall Flanges over the mounting flange and tighten into place. Repeat for both sides.