



FLOOR BATHSEAL **INSTALLATION INSTRUCTIONS**

Shower Floor Seal is designed to form a physical barrier on the bathroom floor, to help keep the water in the desired area and not all over your bathroom floor.

TOOLS REQUIRED FOR INSTALLATION:

- Box Cutter
- Measuring tape
- Sealant (use with any sealant gun)
- Bathroom floor cleaner
- **Fugi Silicone applicator**
(Optional Tool - Fugi and Silicone removal tool available from ShowerRods.com)

INSTALLATION:

1. Clean the floor area you wish to fit to with your favorite Bathroom Floor Cleaner to remove any products such as shampoo or conditioner from the floor.
2. Remove the Shower Floor Seal from its packaging and lay it on the bathroom floor to decide on the size you need.
3. Cut the profile to the correct size required - relay it in position on the bathroom floor to check it fits properly.
4. Silicone the back of the profile and lay in place on bathroom floor. Remove any surplus sealing with the fugi tool.
5. Leave to set for a minimum of 5 hours before using the bathroom. Your installation is now complete.

