



RECTANGULAR BATHSEAL INSTALLATION INSTRUCTIONS

Bath Seals are essential to prevent water leaks, seal in your tub to a tiled wall and keep away black mold. The bath seals can be retro fitted and are made of solid plastic, so unlike the hollow under tile seals, they don't trap water in and go black and moldy. The Bath Seals are gloss white and are easily cut to size.

TOOLS REQUIRED FOR INSTALLATION:

- Box Cutter
- Measuring tape
- Sealant (use with any sealant gun)
- **Fugi Silicone applicator**
(Optional Tool - Fugi and Silicone removal tool available from ShowerRods.com)



Measure length of bath and transfer measurement to 2m profile - Mark and cut to length by scoring and snapping profile - lay on bath "dry"



Take the appropriate 1m profile and fit it to the long profile behind taps - Mark to size - Cut and fit "dry" - Repeat with remaining profile



Clean Profile - Fit the long length 1st - Add generous silicone with large nozzle - Fit profile and remove excess with Fugi - Now fit end pieces



Change to fine nozzle - Seal in top and bottom of profile with silicon - Fit End Caps - Use Fugi to remove excess silicone - Leave to set 4 hours