



## D-Shaped Shower Rod Installation Instructions

### CONTENT

- (4) Rods (2 corners & 2 straights)
  - (2) Round Flanges (all mounting screws included)
  - (1) Ceiling Support (all mounting hardware included)
  - (2) Inserts
  - (2) Rod Loop Connectors
1. Position **Round Brackets** on desired location on the wall and mark for the screws - drill holes and insert plastic anchors. Repeat for **Ceiling Support Bracket**.
  2. For maximum support on all set screws:
    - Position brackets at the end of each corner rod, and slide "O" loop in the center.
    - Mark location of set screw holes and remove brackets and loop.
    - Drill slightly smaller hole into the rod where it was marked.
    - Assemble brackets and loop back and tighten all set screws into the rod.
  3. Trim **Ceiling Support** to desire length. Fasten Support Rod into Ceiling Support Bracket, and tighten "O" loop set screw onto ceiling support.
  4. Use insert to connect all 3 rods. Connect and tighten Rods into Loop Connectors.
  5. With the help on another person, place assembled D-Rod on marked location and screw the Round Brackets into the wall and Ceiling Support Bracket into the ceiling.

