



Half-Oval Shower Rod Installation Instructions

CONTENT

- (1) Rod
- (2) Rectangular Brackets (all mounting screws included)
- (1) Ceiling Support (all mounting hardware included)

1. Position **Rectangular Brackets** on desired location on the wall and mark for the screws - drill holes and insert plastic anchors. Repeat for **Ceiling Support Bracket**.
2. For maximum support on all set screws:
 - Position brackets at the end of each corner rod, and slide "O" loop in the center.
 - Mark location of set screw holes and remove brackets and loop.
 - Drill slightly smaller hole into the rod where it was marked.
 - Assemble brackets and loop back and tighten all set screws into the rod.
3. Trim **Ceiling Support** to desire length. Fasten Support Rods into Ceiling Support Bracket, and tighten "O" loop set screw onto ceiling support.
4. With the help on another person, place assembled Half Oval Rod on marked location and screw the Rectangular Brackets into the wall and Ceiling Support Brackets into the ceiling.

