



## Suspended Rod with Double Heavy Support Installation Instructions

### CONTENT

- (1) Straight Rod
- (2) End Caps
- (2) 36" Ceiling Support (all mounting hardware included)

### HARDWARE NEEDED

- Phillips head screwdriver
- All-purpose drill
- Hacksaw (if cutting down rod)

### Note: Two people are needed for this installation.

1. Measure the space of the bathroom where the Shower Rod will be placed and if needed use a hacksaw to cut the shower rod and ceiling support to desired length. (Use diagram below to assemble parts to help mark location, with O-Loop about 1 inch from the end of the rod.)
2. If not already installed, place the Caps on each end of the rod.
3. Support Bracket:
  - Position the Support Brackets at the desired location and mark for the screws.
  - Drill the holes and insert the plastic Anchors. (Please Note - depending on what material is in the ceiling, other fasteners than what is included may be required. **This rod is entirely ceiling suspended - and is only as strong as how it is installed.**)
  - Place the Support Brackets onto the ceiling and install the screws.
  - Slide Heavy Support Rod into the Support Brackets on each side and mark the location of Set Screws.
4. O-Loop & Shower Rod:
  - Slide O-Loop on the Shower Rod and mark the location of the bottom Set Screw of the O-Loop.
  - Slide the O-Loop (while attached to the Shower Rod) into the Heavy Support Rod - mark the location for the top Set Screws.
  - Drill slightly smaller holes into the Shower Rod and Heavy Support Rods where it was marked.
  - Place the bottom Set Screws into the O-Loop and **tighten them all the way into the Shower Rod.**
5. Lift the Shower Rod - place O-Loop into the Heavy Support Rods and **tighten the Set Screws all the way in.**

