



Suspended Rod Ceiling to Wall - Heavy Support Installation Instructions

CONTENT

- (1) Straight Rod
- (2) End Caps
- (2) 36" Ceiling Support (all mounting hardware included)

HARDWARE NEEDED

- Phillips head screwdriver
- All-purpose drill
- Hacksaw (if cutting down rod)

Note: Two people are needed for this installation.

1. Measure the space of the bathroom where the Shower Rod will be placed and if needed use a hacksaw to cut the rod and ceiling support to desired length. (Use diagram below to assemble parts to help mark location, with O-Loop about 1 inch from the end of the rod.)
2. If not already installed, place the End Cap on one end of the rod.

Brackets:

- Position the Support Bracket at the desired location and mark for the screws.
 - Drill the holes and insert the plastic Anchors. (Please Note - depending on what material is in the ceiling and wall, other fasteners than what is included may be required. **This rod is only as strong as how it is installed.**)
 - Place the Support Bracket onto the ceiling and install the screws.
 - Follow same steps to place the Wall Bracket onto the wall and install the screws. (*Be aware which side the set screw will be facing!*)
 - Slide Heavy Support Rod into the Support Bracket and mark the location of the Set Screw.
3. O-Loop & Shower Rod:
 - Slide O-Loop on the Shower Rod and mark the location of the bottom Set Screw of the O-Loop.
 - Slide the Shower Rod into the Wall Bracket and the Heavy Support Rod into the O-Loop - mark the location for the remaining Set Screws.
 - Drill slightly smaller holes into the Shower Rod and Heavy Support Rod where it was marked.
 - **Place the bottom Set Screw into the O-Loop and screw it all the way into the Shower Rod.**
 4. Lift the Shower Rod - connect the rod into the Wall Bracket, the O-Loop into the Heavy Support Rod and in turn into the Support Bracket. **Screw the Set Screws all the way into the both rods.**

