

Installation Instructions

888-322-7762

CLASSIC "U" SHOWER ROD

Installation Instructions



1. Place mounting brackets on the wall and mark location of screw holes to be drilled. Drill holes into the wall and fasten mounting brackets.
2. Determine length of ceiling support rod and cut rod down if needed. Thread support ring through one half of the shower rod.
3. Assemble the three sections of the shower rod.
4. Place shower flanges on each end of the shower rod. Put into place at the mounting brackets. Tighten the flange onto the rod with the set screw.
5. Place ceiling support ring at the desired location. Thread rod into the ceiling brackets and install. Place other end of rod into the support ring and tighten into place.