



Suspended Rod with Double Light Support Installation Instructions

CONTENT

- (1) Straight Rod
- (2) End Caps
- (2) 36" Ceiling Support (all mounting hardware included)

HARDWARE NEEDED

- Phillips head screwdriver
- All-purpose drill
- Hacksaw (if cutting down rod)

Note: Two people are needed for this installation.

1. Measure the space of the bathroom where the Shower Rod will be placed and if needed use a hacksaw to cut the shower rod and ceiling support to desired length. (Use diagram below to assemble parts to help mark location, with O-Loop about 1 inch from the end of the rod.)
2. If not already installed, place the Caps on each end of the rod.
3. O-Loop:
 - Slide O-Loop in and mark the location of the bottom set screw of the O-Loop on the Shower Rod.
 - Drill slightly smaller hole into the rod where it was marked.
 - **Place the set screw into the O-Loop and screw it all the way into the rod.**
4. Support Bracket:
 - Position the Support Brackets at the desired location and mark for the screws.
 - Drill the holes and insert the plastic Anchors. (Please Note - depending on what material is in the ceiling, other fasteners than what is included may be required. **This rod is entirely ceiling suspended - and is only as strong as how it is installed.**)
 - Place the Support Brackets onto the ceiling and install the screws.
 - Thread the Light Support Rod into the Bracket on each side.
5. Lift the complete Shower Rod - place Light Support Rod into the O-Loop and tighten the set screw - **DO NOT OVERTIGHTEN.**

