



## DOUBLE SHOWER ROD INSTALLATION INSTRUCTIONS

### TOOLS REQUIRED FOR INSTALLATION:

- Hacksaw
- Level
- Electric drill
- Hammer
- Phillips screw driver

### INSTALLATION:

1. Before installing, measure the distance of the walls with bracket placed on rods, and if needed, trim the rod equally at both sides with a **hacksaw**.
2. Decide on the location of the rod. Remove the bracket's faceplate, use a **level** tool, and with an **electric drill** make light marks through the holes where it will be drilled.
3. Place bracket down, drill on the previous made marks, and with a **hammer** lightly tape available anchors through the holes.
4. Place bracket on the wall and with a **screw driver** tighten all 4 screws available.
5. Repeat steps 2-4 for other end bracket.
6. Slide bracket's faceplate onto both end of the rods. Place each end of the rods into the bracket's nubs. - Repeat for other end.
7. Make sure set screw is tighten with a **screw driver** and slide faceplate onto the bracket..

**Rod is complete.**

