



PARTIAL SLOPED SHOWER ROD INSTALLATION INSTRUCTIONS

TOOLS REQUIRED FOR INSTALLATION:

- Hacksaw
- Level
- Electric drill
- Pencil
- 6 mm Hex Key
- Flat Screwdriver

INCLUDES:

- (1) 60" Shower Rod
- (2) Wall Brackets
- (1) Swivel Angle Joint
- (1) Mounting Glue

INSTALLATION:

1. Add a small amount of glue at the top of the 3/4" diameter end of the Swivel Joint (**A**) and place angle joint into one side of the rod. Allow 15 minutes to dry.
2. Place brackets at the desired location and mark for the screws. Drill holes into the wall and insert the plastic anchors.
3. Lay out the shower rod and determine the length needed. Trim the rod.
4. Place one bracket at the end of the Swivel Joint 1" diameter side (**B**) and the other bracket at the end of the rod. With the help of another person, hold rod up and screw the brackets into place. Tighten Swivel Joint and bracket set screws.

Rod is complete.

