



Neo-Angle Shower Rod Installation Instructions

CONTENT

- (2) Neo-Angle Rods
- (1) Center Rod
- (2) Flanges
- (1) 36" Ceiling Support (all mounting hardware included)

HARDWARE NEEDED

- Phillips head screwdriver
- All-purpose drill
- Hacksaw (if cutting down rod)

Note: Two people are needed for this installation.

1. Take the flange's mounting bracket and mark the holes in the wall that are to be drilled.
2. Drill the holes and fasten the mounting brackets to the wall.
3. Measure the lengths of tubing and cut down accordingly. A tubing cutter can be used to cut down the rod.
4. Mark where the bracket's set screw will fit on end of rod and drill.
5. Slide splice into rod. Equal distance on ends.
6. Assemble the shower rod by sliding the lengths of tubing together.
7. Insert the wall brackets over the ends of each side of the rod. Fasten down the set screw into the previous drilled hole.
8. Place the assembled rod onto the mounting brackets and tighten screws that holds the brackets into wall.

