



## Neo-Angle Shower Rod Installation Instructions

### CONTENT

- (2) Neo-Angle Rods
- (2) Flanges
- (1) 36" Ceiling Support (all mounting hardware included)

### HARDWARE NEEDED

- Phillips head screwdriver
- All-purpose drill
- Hacksaw (if cutting down rod)

**Note: Two people are needed for this installation.**

1. Take the flange's mounting bracket and mark the holes in the wall that are to be drilled.
2. Drill the holes and fasten the mounting brackets to the wall.
3. Measure the lengths of tubing and cut down accordingly. A tubing cutter can be used to cut down the rod.
4. Mark where the bracket's set screw will fit on end of rod and drill.
5. Measure the ceiling support and cut the non-threaded side of the rod if necessary.
6. Drill holes and fasten the ceiling support bracket to the ceiling. Screw the support rod into the ceiling support bracket.
7. Insert the ceiling support loop onto the center tubing.
8. Slide splice into center rod. Equal distance on each end.
9. Assemble the shower rod by sliding the lengths of tubing into each other.
10. Insert the wall flanges over the ends of each side of the rod. Fasten down the set screw that holds the flange onto the rod.
11. Place the unit onto the mounting brackets and tighten the set screw that holds the flange into place.

