

Installation Instructions

888-322-7762

TRAK Corner Rod Installation

The Corner TRAK shower rod allows your shower curtain to move around the rod without obstruction from the ceiling supports.

The TRAK rod is made from 1" Square -- lightweight aluminum. The Ceiling Supports are made from brass tubing and can be cut on site to a shorter size with a tubing cutter or hack saw.

Included:

(1) 36" Ceiling Support Rod - (2) Wall Flanges - (24) Glide Pins - (1) Internal Connectors

- 1) We recommend that installation is done with two people.
- 2) Assemble the two frames by inserting the (1) connectors in the end of each frame. Push the frames together to form one frame.
- 3) Carefully bend the Corner Trak in place. Note -- please bend the sections only once as more may cause the Trak to break.
- 4) Determine the length needed for ceiling support and cut down to size if needed.
- 5) Mount the wall flanges onto the wall. They are surface mounted.
- 6) From the bottom of the shower rod -- place the ceiling support rod through the screw holes supplied. Carefully -- tighten the screw to the end of the support rod. Do Not Over Tighten !!
- 7) Assemble the ceiling flanges over the support rods and tighten in place with the set screw. Again -- do not over tighten.
- 8) Place shower rod on the ceiling and mark the location of the holes to be drilled. Insert the included plastic anchors into the ceiling. Then, screw the ceiling flanges onto the ceiling.

Please Note: This shower rod is made of a lightweight aluminum material. Please carefully bend the corner once - as more may cause the Trak to break.

