

## TRADITIONAL OVAL SHOWER ROD - WALL MOUNTED

This application is best if there is blocking in the wall - for strength and stability of the rod.

### TOOLS REQUIRED FOR INSTALLATION:

- Mounting screws and wall plugs (not included)
- Electric drill
- Measuring tape
- Level
- Screw driver

### INSTALLATION:

1. Select mounting location. Place shower brackets at location and mark wall for screws. (**Note - mounting screws are not included**)
2. Make sure it is level. Drill and install wall plugs.
3. Take nut off threaded rod on wall support.
4. Insert threaded portion in wall tube and insert into wall flange.
5. Tighten nut onto back of wall flange.
6. Thread tube onto the shower rod in the two locations.
7. Hold shower rod unit up to the wall - *two people needed* - secure the wall flanges to the wall with screws.

