



Suspended Corner Shower Rod Installation Instructions

CONTENT

- (2) Rods (1 corner & 1 straight)
- (2) End Caps
- (2) 36" Ceiling Support (all mounting hardware included)
- (1) Insert

1. Assembling ceiling support - screw **Support Bracket** into **Ceiling Support Rod**. Insert **O-Loop** into Ceiling Support Rod and tighten top set screw.
2. Assemble rods by using **Insert** to connect them both. *Lift rod onto desired location and if needed, trim ends to desired length.*
3. Slide both Ceiling Supports on desired location at each end of the rods and tighten bottom O-Loop Set Screws. Plug-in **End Caps** on each end of rods.
4. Have one person lift the rod onto desired location, while the other person marks for the screws on ceiling.
5. Place rod down and drill holes and insert plastic Anchors.
6. *If trimming Ceiling Supports, trim both equally on the un-threaded side to desire length.*
7. With the help of another person, lift assembled Corner Rod onto previously marked locations and use the Mounting Screws to secure rod into place.

