

CURVED U-ROD SHOWER ROD INSTALLATION INSTRUCTIONS

TOOLS REQUIRED FOR INSTALLATION:

- Electric drill
- Measuring tape
- Masking tape
- Screw driver
- Hacksaw

INSTALLATION:

1. Decide on the optimum length and width of your shower rail and using a hacksaw cut the stainless steel rods to size. *(Tip - Rods should be slightly shorter than the length and width of your bath)*
Fit the rod together on a flat surface to check it assembles OK
2. Clean 2cm inside of the tubes and also the swivel joint with a clean cloth. **Note - Take care there may be sharp metal exposed at the ends.** Test the swivel joint fits into the tubes before adding glue. On a flat surface add a few drops to the inside of each tube. Push swivel joint into the crescent rod and straight rod, again making sure the rods are on a flat surface when the glue sets. **(VERY IMPORTANT)**
3. Fix masking tape to the area where you will fix the first bracket "a". Carefully mark and drill the two holes, then add the rawplugs and fix bracket "a" to wall.
4. Hold the crescent rod up against the wall as per Diagram 1 and slide tube into bracket "a". Mark the position of the point where the 2nd tube touches the wall on your newly marked horizontal line with a pencil "c". Normally you would site the bracket just inside the edge of your bath of you have measured correctly. Mark and drill and fix the 2nd bracket.
5. Insert assembled rod into the wall bracket "a" then check that the rod is level. Mark position of the second bracket "c". Carefully mask the area off, then drill the 8mm holes and add the rawplugs and wall bracket.
6. Carefully slide ceiling support ring into the curved rod. Position and tighten set screws.




Diagram 1

- Tape up area with masking tape
- Mark & drill holes
- Add rawplugs & fix bracket to tiled wall



Wall Brackets
"a" & "c"

- Ensure rod is level and straight
- Mark new bracket and repeat above procedure then fix rod in place





7. Slide rod into brackets “a & c”. Hold rod in place to make ceiling support measurement.
8. Measure from curved rod to ceiling “b” and cut the vertical rod to size. Push vertical rod onto “T” piece, followed by final bracket. Mark 3 ceiling holes, use 8mm drill, rawplug and fix bracket. (*Note: You may need extra bracing in your ceiling space to screw into*)
9. Tighten all of the allen screws on all brackets with the allen key provided to finish your installation.