






PVD Polished Brass



Polished Brass



Unlacquered Brass



Brushed Brass




Antique Brass



Oil Rubbed Bronze



Polished Nickel



Brushed Nickel




Antique Nickel



Flat Black




Polished Chrome



Brushed Chrome

How to Determine the Radius of a Hinge

To determine if you have 1/4" or 5/8" radius corner hinge, measure the beginning of the curve to where the corner of the hinge would be if it were square.



Location of Hinge on the Door

Upper hinge 5" from top jamb to top edge of barrel.

Bottom hinge 10" from bottom edge of barrel to finished floor.

Middle centered between top and bottom hinges.

How to Select the Proper Hinge Size

To choose the proper hinge size consider the following:

THICKNESS OF DOOR	WIDTH OF DOOR	HEIGHT OF HINGE
1-3/8" Door	To 32"	3-1/2"
1-3/8" Door	32" to 36"	4"
1-3/4" Door	To 36"	4-1/2"
1-3/4" Door	36" to 48"	5"
1-3/4" Door	Over 48"	6"
2", 2-1/4", 2-1/2" Door	To 42"	5" Commercial
2", 2-1/4", 2-1/2" Door	Over 42"	6" Commercial

Number of Hinges per Door

As a general rule you will want to use 1 hinge per every 30" of door or fraction thereof. Referring to door height:

Doors up to 60" need 2 hinges. Doors over 60" but not over 90" need 3 hinges. Doors over 90" but not over 120" need 4 hinges.