



## **SLOPED CEILING SHOWER ROD** **INSTALLATION INSTRUCTIONS**

This rod is used for providing a solution to baths and showers in the roof space or eaves of the property.

The rod is made oversized, so you may need to cut some tube from each end - We recommend using a stainless steel hacksaw blade to do this.

### **TOOLS REQUIRED FOR INSTALLATION:**

- Electric drill
- Measuring tape
- Screw driver
- Hacksaw

### **INSTALLATION:**

1. Decide on the height of the rod and put a piece of masking tape at the point (a-c).
2. Place swivel end flange on wall, and mark the location of the two mounting screws. Insert the plastic anchors into the wall. Position the bracket and screw in place.
3. Place swivel into the bracket and insert screws.
4. Determine if the 48" tubing and 36" ceiling support needs to be trimmed.
5. Insert the ends of the swivel joint (d) into each rod.
6. Slide "O" loop of the ceiling support onto the rod. Install ceiling support flange into the ceiling. Thread ceiling support rod into the flange.
7. Place rod into the swivel flanges and ceiling support. Tighten all set screws into place.

